



Stride length:
51cm



Distance between pedals:
7cm



Maximum user weight:
180kg



Dimensions:
204 x 79 x 165cm

SPECIFICATIONS

- **Electromagnetic and self-generating braking system.** No electrical connection required
- Autoguidance system that allows to increase the speed of stride with no risk.
- **Pulse sensors** for heart rate monitoring: measured either by contact with the handlebar or telemetry (Integrated POLAR compatible receiver).
- **Poly-V belt drive system** to ensure silent exercise and minimal maintenance.
- **Anti-slip footplates.**
- **25 Resistance levels.**
- **Double handlebar:** the arms work together simultaneously with the legs, providing a full-body exercise.
- **Structure of high strength steel.**
- **Oversized bearings and footrest,** more comfortable and safe.
- **Integrated bottle holder and mobile/tablet holder.**
- **Front wheels** for easy transport.
- **Adjustable stabilizers.**
- **Minimum distance between pedals** in order to ensure a perfect body position.
- **New designed engine and chassis:** more attractive, stylish and ergonomic.
- **EC Declaration of Conformity.**
- **Compliance with EU directive 89/336/EEC** Electromagnetic Compatibility and European Standard UNE-EN 957 on fixed and mobile equipment.
- **Weight:** 121kg

LED PREMIUM



- **DOT MATRIX:** Upper alphanumeric display that guides the user during exercise selection and execution, and shows information about the exercise during and after the session. The lower LEDs display the different pre-programmed effort profiles (programs) available for selection and, during the exercise, indicate the current effort level in real time.
- **Bluetooth FTMS Connectivity:** In addition to connecting any mobile device to the machine, it also allows users to sync with the most popular training apps on the market.
- **Training Programs:** 1 MANUAL profile program; 8 programs with predefined profiles; 1 user-programmable profile (USER); male and female TEST programs; and a constant heart rate (HR) program.
- **On-Screen Information:** Speed, distance, time, calories burned, heart rate, training program, level, and incline.
- **Emergency Stop Button** on the front toolbar and MOB automatic stop system (chain).
- **User-Friendly Design:** Engineered to ensure users get the most out of the equipment from day one. Intuitive display and large buttons for quick identification.
- **Accessories:** Audio input for headphones and USB port for charging mobile devices.
- **RFID Connection:** Enables fast and automatic user identification for login, workout tracking, and routine personalization.
- **QR Code** for registering with the Gymloop training app.