

L815 Press bench

- **Three layer coating.** Enhanced by an initial anti-corrosion primer, followed by an eposxy powder layer and a lacquer or barnish.
- **Injected core fireproof seat.** Unlike the classic foam padded particle boards, the injected core offers the advantage of uniformity, anti-distortion and greater anti-bacterial protection.
- **Resistance adapted to all the strength** moments developed throughout the whole movement.
- **Designed for optimum exercise biomechanics.** Guarantee smooth, natural movements for full muscle concentration
- **Structure raised 50mm above floor level with rubber tipped feet.** This provides access for cleaning and vacuuming without scratching the paint.
- **Structure, loads and fatigue resistance according to the TÜV standard.**
- **Round edges with elliptical section in order to avoid cuts and knocks.**
- **Reinforced frame,** for more security and protection.
- **Guarantees free, stable and natural guided movements.**
- **3 training positions for the bar** for more varied exercise.
- **Side storage racks for disks.**
- **4 mm thick ST-37.. High durability**

Muscles:



Specifications:

Length: 170 cm / 67 in
 Width: 166 cm / 65,4 in
 Height: 137 cm / 54 in
 Weight: 69 Kg / 152,11 lbs

