



L550 Lat pull

• Front and rear fairings. Provides greater security to the user during exercise, avoiding accidents while the plates are moving.

• Setting elements are bright contrasting yellow. They provide a quick and easy visual identification of the selectors to be adjusted by any user, without help from the coach.

• Visual level indicator of weight training in 3 colors depending on the level of charge: Light, medium y advanced (green, yellow and red). Intuitive system that helps the user to quickly identify the load and the development or progression at the exercise.

• **Double roll up for leg support adjustable in 10 positions**. It fixes the user's position and prevents it from moving during the exercise.

· Posibility of performing a double exercise: lat pull and rower.

• Design with lower profile and solid outline. For a more visually striking and elegant line.





Specifications:

Length: 122 cm / 48 in Width: 185 cm / 72,8 in Heiht: 220 cm / 86,6 in Weight: 243 Kg / 536 lbs Weight stack: 125 Kg / 275 lbs







L550 Lat pull

- Structure, loads and fatigue resistance according to the TÜV standard.
- Reinforced frame, for more security and protection.
- Guarantees free, stable and natural guided movements.
- Work loads adapted both to beginners and advanced users.

• **Designed for optimum exercise biomechanics**. Guarantee smooth, natural movements for full muscle concentration

• 4 mm thick ST-37 / 40 steel frame. High durability.

• Structure raised 50mm above floor level with rubber tipped feet. This provides access for cleaning and vacuuming without scratching the paint.

- Round edges with elliptical section in order to avoid cuts and knocks.
- High protection polycarbonate fairings. Provide prevention against accidents. Very easy to clean.

• Information panel showing worked muscle groups and exercise position. This helps the user to identify the machine quickly and use it correctly.

• Three layer coating. Enhanced by an initial anti-corrosion primer, followed by an eposxy powder layer and a lacquer or barnish.

• **Injected core fireproof seat**. Unlike the classic foam padded particle boards, the injected core offers the advantage of uniformity, anti-distortion and greater anti-bacterial protection.

• **Magnetic weight plate selector**. The magnets ensure that there is no possibility of the selector coming out during training.

- Easy access to all elements of control and load selection from the working position of the user.
- High resistance 5 mm thick coated steel cable. For a smooth, secure performance.
- **Resistance adapted to all the strength** moments developed throughout the whole movement.

