

L350 Multipress

- **Multipress with chromed bar and lineal bearings.**
- **For discs of 28 mm or 50 mm (olympic), thanks to the adapter included as standard.**
- **Designed for optimum exercise biomechanics.** Guarantee smooth, natural movements for full muscle concentration.
- **Reinforced frame,** for more security and protection.
- **Three layer coating.** The design of this professional, up-to-date, stylish system is enhanced still further by its 3-layer coating comprising an initial anti-corrosion primer, for guaranteed durability, followed by an epoxy powder layer and fin.
- **Structure raised 50mm above floor level with rubber tipped feet.** This provides access for cleaning and vacuuming without scratching the paint.
- **Chrome bar with knurled grip,** which increases the adherence in the grip.
- **10 training height points for the bar.** Allows more varied workout.
- **Bar lock security system, swivel and height adjustable.** Allows a safer exercise, preventing the bar from falling on the user in case of accident.
- **4 racks on the rear part for storing discs.**
- **4 mm thick ST-37 / 40 steel frame.** For guaranteed durability
- **Tubes with rounded elliptical section,** that prevent cuts and blows.
- **Use of laser cutting technology.** For optimum tube cutting precision.

Specifications:

Length: 140cm / 55"
Width: 193cm / 76"
Height: 212 cm / 83"
Weight: 134Kg / 295.41 lbs.

