

L825 Multi position bench

- **Designed for optimum exercise biomechanics.** Guarantee smooth, natural movements for full muscle concentration
- **Structure raised 50mm above floor level with rubber tipped feet.** This provides access for cleaning and vacuuming without scratching the paint.
- **Three layer coating.** Enhanced by an initial anti-corrosion primer, followed by an eposxy powder layer and a lacquer or barnish.
- **Injected core fireproof seat.** Unlike the classic foam padded particle boards, the injected core offers the advantage of uniformity, anti-distortion and greater anti-bacterial protection.
- **Resistance adapted to all the strength** moments developed throughout the whole movement.
- **Setting elements are bright contrasting yellow.** They provide a quick and easy visual identification of the selectors to be adjusted by any user, without help from the coach.
- **Round edges with elliptical section in order to avoid cuts and knocks.**
- **Back rest and seat double adjustment in height and inclination.**
Makes possible the adaptation of the bench to all kind of users and a more varied exercise.
- **Rubber tipped feet that protect the floor from scratches.**
- **Structure, loads and fatigue resistance according to the TÜV standard.**
- **Reinforced frame,** for more security and protection.
- **4 mm thick ST-37. High durability.**

Specifications:

Length: 121,2 cm / 47,8 in
Width: 75 cm / 29,6 in
Height: 46,5 cm / 18,3 in
Weight: 37 Kg / 81,57 lbs

