



Running surface:

155 x 55cm



Motor:

3.5HP



Speed:

0.8 - 22km/h



Tilt

15%



Maximum user weight:

150kg



Dimensions:

200x93x148 cm



Bluetooth FTMS Connectivity

SPECIFICATIONS

- **Pro-Tonic Smart Impact Absorption System.** The elastomers allow a more fluid running, as it controls and absorbs the force of each step on the board, helping to maintain a constant speed during exercise.
- **Progressive damping elastomers.** Its advanced technology elastomers gently absorb the first impact of the feet and harden the damping as users bend and lift their feet from the platform. This ensures correct damping that prevents joint and muscle pain in the knees and feet.
- **Aluminium lateral profiles with non-slip surfaces,** which help to prevent slips and falls during exercise
- **Painted ABS plastic case,** with technology from the automotive industry.
- **Band with tough, flexible, slip resistant, absorbent PVC surface.** This surface is highly resistant to abrasion, mechanical strength and shock proof and it is also recyclable.
- **Monitored heart rate:** measured either by contact with the handlebar or via telemetry (Integrated POLAR compatible receiver).
- **Height adjustable feet,** for the maximum stability.
- **Easy Toolbar for quick, instant access built into the front handrail,** this includes pulse rate contact sensors, one-finger speed and tilt buttons and emergency stop.
- **Wheels for easy transport**
- **Heart Rate Constant program (HRC).** Allows cardiovascular zones to be targetted during exercise. Automatically controls workout intensity to maintain effort at selected pulselimits.
- **NO lubrication needed:** Includes a revolutionary combination of belt and deck with a HST Phenolic wax unique in the market that provides a low maintenance system, and eliminates the need of lubrication for an estimated period of 6 months or 1 year (depending on the environmental conditions of the room and the frequency of use).
- **Connection for mp3 and built-in speakers,** which let users listen to their own music while exercising.
- **Man / Woman Fitness Test.** Allows to evaluate the shape and physical condition of the user.

LED PREMIUM



- **DOT MATRIX:** Top alphanumeric display that guides the user during exercise selection and performance and displays exercise information during and after exercise. The lower LEDs show the different pre-programmed effort profiles (programs) that can be selected and, during exercise, the level of effort being made at any given moment.
- **FTMS Bluetooth Connectivity:** apart from connecting any mobile device to the machine, it also allows users to connect with the most popular training Apps on the market.
- **Training programs:** 1 MANUAL profile program; 8 Programs with predefined profiles; a user-programmable profile (USER); male TEST and female TEST programs; and constant heart rate (HR) program.
- **On Screen Information:** Speed, distance, time, burned calories, pulse, training program, level and inclination.
- **Emergency Stop Button** at front Toolbar and automatic stop system MOB (string)
- **User friendly:** designed for users to get the most out of it in the easiest way out of the box. Intuitive display and large buttons that help to identify them quickly.
- **Accessories:** audio input for earphones and USB port for charging mobile devices.
- **RFID Connection:** Enables fast and automatic user identification for login, workout tracking, and routine personalization.
- **QR Code** for registering with the Gymloop training app.